



Single Use Wet Curing Blanket

Application

Place wet, UltraCure NCF™ wet cure covering in widest practical width as soon as concrete has hardened sufficiently to prevent surface damage. Each roll shall overlap the previous roll by at least 3”.

Overlap the slab edges and into doorways at least 12”. Immediately repair any holes or tears during the curing period using wet cure material and water.

Cover the entire surface area including edges of paving and sidewalks. Install UltraCure NCF™ moisture containing wet cure covering material as per manufacturer’s written instructions.

Wet surface of slab-on-grade with 1/8” to 1/4” inch of water to cover entire surface area of slab, then slowly unroll the UltraCureNCF™ product onto slab using the roller squeegee applicator. No portion of this product shall be re-used once it has been put into use on a slab on grade or other concrete application.

Maintain UltraCureNCF™ in place on concrete for a period of not more than seven (7) days after placement. Continuous inspection for the purpose of maintaining 100 % curing blanket contact with surface to be cured is recommended during the curing period.

Remove the UltraCureNCF™ curing blanket on the seventh (7th) day following initial installation, and discard along with other construction debris