

C SLAB KEY PLAN

SAW-CUT EXISTING SLAB FULL DEPTH. APPLY BOND BREAK TO SLAB VERTICAL EDGE (AVOID APPLYING TO TOP OF SLAB)

5 1/2"
(MATCH
EXISTING)
MID-DEPTH

EXISTING
SLAB

RESAW JT AND
FILL, REF 3B-S2


NEW SLAB

1/4" EZ-DOWEL (BY EZ-FORM
- REF SPECS) AT 24" OC

NOTE:
IF EXISTING SLAB IS
LESS THAN 3 1/2"
THICK, NOTIFY OWNER'S
REPRESENTATIVE.

1/4" THICK x 2 1/2" DEEP PLUNGE SAW
CUT (USING 12" DIA SAW BLADE) IN FACE
OF EXISTING SLAB; CUT SHALL BE LEVEL,
REF SPECS FOR TOLERANCES AND DUST
COLLECTION PROCEDURES

B EZ-DOWEL PLATE DOWEL



A CUT SLOT FOR PLATE DOWELS

3D NEW TO EXISTING SLAB (SLAB EDGE LENGTHS GREATER THAN 4'-0")

Johnston Burkholder Associates
CONSULTING STRUCTURAL ENGINEERS
930 CENTRAL - KANSAS CITY, MISSOURI 64106
© Copyright 2010 Johnston Burkholder Associates
NC CORPORATE NUMBER: P-0672
EXPIRES 06/30/10

SLAB
REPLACEMENT
PLANS AND
DETAILS

SHEET:

S2